





# AZ988

## MECHANICAL DATA

<p><b>Outline Dimensions</b> <b>C1</b></p>	<p><b>BOTTOM VIEW</b></p>	<p><b>Wiring Diagram</b> <b>VIEWED TOWARD TERMINALS</b></p>
<p><b>Outline Dimensions</b> <b>C2</b></p>	<p><b>BOTTOM VIEW</b></p>	<p><b>Wiring Diagram</b> <b>VIEWED TOWARD TERMINALS</b></p>
<p><b>Outline Dimensions</b> <b>C3</b></p>	<p><b>BOTTOM VIEW</b></p>	<p><b>Wiring Diagram</b> <b>VIEWED TOWARD TERMINALS</b></p>
<p><b>ST977-U1</b></p> <p><b>PC BOARD LAYOUT</b></p>	<p><b>ST977-U2</b></p>	

W/in 1 2 3 4 5 1949u

\* N ORMRELAYTERMINALISREMOVED

**AMERICAN ZETTLER, INC.** [www.azettler.com](http://www.azettler.com)

75 COLUMBIA • ALISO VIEJO, CA 92656 • PHONE: (949) 831-5000 • FAX: (949) 831-8642 • E-MAIL: SALES@AZETTLER.COM